

ELD + GPS

Quick Start Guide



WE'RE CONFIDENT WE CAN MAKE IT RIGHT!

If you have any questions or problems with your ELD + GPS system, please give us a call before you make a return.

Linxup Customer Support Phone: 1-877-899-3039

Email: support@linxup.com

How are we doing? We'd love to know.

We hope you will be pleased with your order and the service you receive. We love to hear from customers about features they love, and ways we can continue to improve your experience. Leave us a review where you made your purchase. Thank you!

For more valuable information, please like us on Facebook, and follow us on Twitter and LinkedIn. You can also check out our blog at www.linxup.com/blog



Activate Your Device

- 1 Open a web browser and go to: www.linxup.com/getstarted
- 2 Create an account, or log in to your existing account.

New Customers
Fill out the following to complete your registration:

Activation Code:

E-mail Address:

Create Your Password:

Confirm Password:

I agree to the [Terms & Conditions](#)

Next

Already a Customer?
Simply log in and we'll walk you through the process of adding your new units.

Email Address:


Password:

Sign In

[Forgot Your Password?](#)

If not already on file, you may be prompted for your billing information.

Here's your device activation code:



- 3 Follow the instructions for activating your device(s).

Make sure the activation code in this guide matches the code on screen. Or, if your activation code does not show up re-enter it and press continue.

Set Up eFleetSuite

- 4 Navigate to the ELD eFleetSuite login page by clicking the ELD button at the top of your screen. Sign in using the eFleetSuite credentials emailed to you. Please allow 2-3 business days for delivery.
- 5 Set up your home terminal(s).

A Select 'Home Terminals' in the 'ADMIN' dropdown.

B Click 'New.'

C Fill out the form, then click 'Save.'

- 6 Set up your driver(s). Make sure you have the driver's license number available.

A Select 'Drivers' in the 'SETUP' dropdown.

B Click 'New.'

C Your drivers will use 'Driver ID' to log in to the app.

D Make sure to check the box to give Web Access to drivers.

E Complete the form, then click 'Save.'

The system will create a temporary password for the driver. See the Driver's App Guide for details.

Install Your Device

- 7 You will need your device, the cord, and the tablet. If you have ordered more than one tablet, you may choose any tablet that you have received, as these have not been paired yet. Begin with the ignition and the tablet powered off.
- 8 **J-BUS Devices:** Connect the cord to the device, then plug the device into the J-Bus port.
- OBD Devices:** Connect the OBD extension cord to the device, then plug the device into the OBDII port.
- 9 Turn on the ignition, and verify green and orange lights on the device.
- 10 Power on the tablet. The app will automatically start. The tablet will then recognize all devices within range. The device at the top of the list will be the one closest to you. Double check by matching the serial number, then choose the device.
- 11 **OBD devices only** - A pop-up window will prompt you to input the current odometer reading of the vehicle.

Your installation is complete!

Per regulation, for the first 10 days the system may not display available hours on the tablet. The system is still capturing information and generating logs, which are available in the eFleetSuite portal.



Get to Know the Linxup System



Setup

Customize the Linxup system to make it work best for you.

Set thresholds for speeding alerts and authorized hours.

Click to edit.



Alerts

Use the Alerts section to review all alerts that occur within defineable dates.

Click the address to see the location on a map.



Reports

Review all fleet reports from the fleet activity dashboard.



Maintenance

Make vehicle maintenance easier with scheduled maintenance reminders.

Vehicle	Service Type	Service Interval	Next Service Due
Vehicle 2	General Service	Every 15,000 miles	9,902 miles overdue
Vehicle 4	Preventive Maintenance	Every 5,000 miles	543 miles overdue
Vehicle 1	Oil Change	Every 120 days	6 days overdue
Vehicle 2	General Service	Every 10 days	4 days to go
Vehicle 3	General Service	Every 30 days	30 days to go
Vehicle 1	Tire Rotation		to go
Vehicle 4	Scheduled Service		
Vehicle 2	Scheduled Service		
Vehicle 1	Preventive Maintenance		
Vehicle 2	Preventive Maintenance		



ELD

Sign in to the eFleetSuite to review logs and reports

Click HOS or DVIR for a description of each log, checklist, and report available.

Want to learn more about the Linxup ELD system? Visit the help pages in your ELD portal to sign up to attend one of our informative webinars!



Map

Locate your vehicle at all times, view its history, and manage your geofences.

Use Route Replay to coach your driver by reviewing their driving history.

Locate your vehicle at all times.

A geofence can be an office, job site, or a restricted area and is a virtual boundary on the map.

Need help? Click the 'Help' icon, sign up for a webinar, or connect with a customer service agent.

Download now! Linxup Mobile App

Track and monitor fleet driving with: Alerts, Real-time GPS tracking, Driving report card

